

## GB AWO/R 5206

## PROGRAMME CHART


### A. "Door open" indication

This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately, e.g.:

### B. "Service" indication

### C. "Water tap closed" indication

### D. "Clean pump" indication



### E. Programme selector

### F. "Start/Pause" button

### G. Programme sequence indicator



### H. "Reset" button

Programme	Care Labels	Type of wash / Notes  - for temperature selection, respect the manufacturer's recommendations on the care label	Max. Load  kg	Detergents and Additives			Special options		Spin Speed  rpm
				Pre-wash	Main Wash	Softener	Spin speed reduction 600 rpm	Rinse hold	
<b>Cotton with prewash</b> 95 °C		Heavily soiled, long wearing and temperature stable textiles in cotton and linen (bed linen, table linen, underwear, shirts etc.).	6.0	Yes	Yes <sup>1)</sup>	*	*	*	1200
<b>Cotton</b> 40 - 60 - 95 °C		Normally to heavily soiled bed linen, table linen and underwear, towels, shirts etc. made of cotton and linen.	5.0	–	Yes	*	*	*	1200
<b>Synthetics with prewash</b> 60 °C		Heavily soiled blouses, shirts, overalls etc. made of polyester (Diolen, Trevira), polyamide (Perlon, Nylon) or blends with cotton.	2.5	Yes	Yes <sup>1)</sup>	*	*	*	1000 <sup>2)</sup>
<b>Synthetics</b> 30 - 40 - 60 °C		Normally soiled blouses, shirts, overalls etc. made of polyester (Diolen, Trevira), polyamide (Perlon, Nylon) or blends with cotton.	2.5	–	Yes	*	*	*	1000 <sup>2)</sup>
<b>Delicates</b> 30 °C		Curtains and delicate clothing, dresses, skirts, shirts and blouses.	1.5	–	Yes	*	*	*	1000 <sup>2)</sup>
<b>Quick wash</b>		Shortly worn outer clothing made of cotton, polyester, polyamide and blends with cotton.	3.0	–	Yes	*	*	*	1200
<b>Wool</b> Cold - 40 °C		Only woollens with a felt-free finish, labelled with the woolmark and identified as machine washable. <i>If you select "Rinse hold" do not leave items to soak for too long.</i>	1.0	–	Yes	*	*	*	1000 <sup>2)</sup>
<b>Handwash</b> 30 - 40 °C		Textiles made of linen, silk, wool and viscose marked as "handwashable". <i>If you select "Rinse hold" do not leave items to soak for too long. A very gentle spin is used in this programme.</i>	1.0	–	Yes	*	–	*	400 <sup>3)</sup>
Rinse & Spin	–	Same as the last rinse and the final spin in the "Cotton" programme.	6.0	–	–	*	*	*	1200
Spin	–	In this programme spinning is intensive. Same as the spin cycle in the "Cotton" programme.	6.0	–	–	–	*	–	1200
Gentle Spin	–	In this programme spinning is gentle. Same as the spin cycle in the "Wool" programme.	1.0	–	–	–	*	–	1000 <sup>2)</sup>
Drain	–	Water is drained only without any spinning. Alternative method of terminating programme after "Rinse Hold".	–	–	–	–	–	–	–

\* : option / Yes : dosing required

<sup>1)</sup> Do not use liquid detergents.

<sup>2)</sup> For improved garment care spin speed is restricted to 1000 rpm in this programme.

<sup>3)</sup> For improved garment care spin speed is restricted to 400 rpm in this programme.

Whirlpool is a registered trademark of Whirlpool USA.

**5019 301 10408**

## CONSUMPTION DATA

Programme	Temperature Selector (°C)	Load (kg)	Water (l)	Energy (kWh)	Approx. Programme Duration (hours : minutes)
Cotton	95	6.0	59*	1.90	2:00
Cotton**	60	6.0	49	1.14	2:20
Cotton	40	5.0	56	0.70	2:00
Synthetics	60	2.5	50*	0.80	1:35
Synthetics	40	2.5	46	0.50	1:20
Delicates	30	1.5	60	0.50	0:45
Quick wash	30	3.0	41	0.40	0:30
Wool	40	1.0	60	0.50	0:45
Handwash	40	1.0	45	0.50	0:40

Consumption values were measured in normalized conditions in compliance with standard IEC/EN 60 456. Consumption data in the home may vary with respect to the values in the table in relation to the water supply pressure and temperature, the load and the type of wash.

\* To reduce the water temperature, some cold water is added at the end of the main wash cycle, before the pump drains the water out.

\*\* Reference Programme for Energy Label.

## ADD DETERGENTS, CLOSE THE DOOR AND SELECT THE PROGRAMME

Add detergents as indicated on the front page and as described in your Instructions for Use. Close the door and turn the **programme selector** to the desired programme and temperature. The indication lamp next to the **“Start/Pause”** button flashes.

## SELECT ANY DESIRED OPTION

Push the button(s) of any option(s) desired - the respective indication lamp lights up.

When the combination of programme and additional option(s) is not possible, the indication lights switch off automatically. Unsuitable combinations of options are deselected automatically.

### “Spin speed reduction 600 rpm” button

- Reduces the predetermined automatic maximum spin speed to treat your laundry more gently.

### “Rinse hold” button

- The laundry remains in the last rinse water without progressing to the final spin cycle to avoid creasing and prevent colours from changing.
- This option is particularly recommended for the programmes “Synthetics” and “Delicates”.
- It is particularly useful if you want to postpone spinning to a later time, or if you want to drain only.  
**Note:** The programme stops to “Rinse hold” at the time the “Anticrese” light in the programme sequence indication is on. The indication lamp next to the **“Start/Pause”** button flashes.

### Terminate the “Rinse hold” option:

- Press the **“Start/Pause”** button; the programme will terminate automatically with the final spin cycle for the present wash programme.
- If you do not wish to spin the clothes, turn the programme selector knob to the “Drain” programme and press the **“Start/Pause”** button.

## PROGRAMME START

Open the tap and press the **“Start/Pause”** button. The indication lamp next to the **“Start/Pause”** button lights up. The programme sequence indicator shows the current programme phase, running from left to right through Wash, Rinse, Spin/Drain. When the programme phase is finished, the corresponding indication goes out.

## “DOOR OPEN” INDICATION

Before starting and after end of a programme, the lamp lights to show the door can be opened. As long as a wash programme is running, the door remains locked and must on no account be forced open. In case you have an urgent need to open it during a running programme, refer to “Cancel (Reset) a running programme before the end”.

## RED INDICATIONS

### “Service”

Lighting up of the “Service” indication can be caused by a fault in an electrical component. Refer to the “Troubleshooting Guide” in your “Instructions for Use”; if the fault persists, contact our After Sales Service.

### “Water tap closed”

The appliance has no or insufficient water supply. Open the water tap: if the indications still lights up, refer to the “Troubleshooting Guide” in the Instructions for Use.

### “Clean pump”

Waste water is not pumped out. Check whether the drain hose is kinked or the filter must be cleaned: in the latter case refer to the Instructions for Use (“Removing the Filter”).

## PROGRAMME END

- All the lights of the programme sequence indicator are off, and the “Door open” indication lights up.
- Turn the programme selector to the “Off/O” position.
  - Close the water tap.
  - Open the door and unload the machine.
  - Leave the door ajar to allow the drum to dry.

## CHANGE PROGRAMME AND/OR OPTIONS AFTER PROGRAMME START

- Press the **“Start/Pause”** button to pause the programme. The light flashes.
- Select the new programme (with temperature), any options and another spin speed if you want.
- Press the **“Start/Pause”** button again. The new programme continues at the same position where the previous programme was interrupted. Do not add detergent for this programme.

## CANCEL (RESET) A RUNNING PROGRAMME BEFORE THE END

The **“Reset”** button cancels a programme before the end.

- Press the **“Reset”** button for at least 3 seconds. Any existing water is drained out before the door can be opened.